Clearlight®

How To Exchange a Bluetooth Board

How to Exchange a Bluetooth Board

You will need:

- Phillips screwdriver or battery drill
- Step Ladder
- 5,5mm Wrench

Important - Please unplug the sauna before starting the exchange

 Using the step ladder go to the roof of the Sauna to locate the Bluetooth Board. The Bluetooth Board can be found on the power cord side of the Sauna. The location is marked with the star. Please unscrew the corresponding entire hatch screws to gain access (area marked by the star in the image below). This may slightly vary depending on the sauna model.




0



Clearlight®

How To Exchange a Bluetooth Board

2. The Bluetooth Board looks like this:



- **3.** Please disconnect the three Molex wire connections and unscrew the 4 nuts (marked with a purple arrow on the picture above).
- **4.** Please place the new Bluetooth Board on the same place, connect the Molex connections, place the nuts and tighten them.
- 5. Put the hatch back in place and tighten the screws.
- 6. The sauna is now ready to use.

support@infraredsauna.eu