

How to Replace a Tile

You will need:

- Phillips screwdriver
- Sharp knife
- Pointed tool

Important - Please disconnect the sauna from the power supply

1. Remove the sticky screw cover on the wooden frame above the tiles (a sharp knife is helpful here). Keep the screw covers safe as you will need to reuse them.



2. Loosen all screws and remove the wooden frame.
3. Lift the faulty tile with a pointed tool and replace it with a new one.
4. Put the wooden frame back on its original position and screw it on again.
5. Stick the screw covers on the screws again.



6. Reconnect the sauna and enjoy your next sauna session.