

### How to Replace a Keypad on a Sanctuary Sauna

#### You will need:

- Phillips screwdriver
- Dull knife if necessary


#### Important - Please disconnect the sauna from the power supply

1. Loosen the screws on the top and the bottom of the wooden frame and remove carefully.



2. It is a good idea to take a photo of the keypad connection before disconnecting the connector.
3. Disconnect the connector. The connector might be covered with a white glue, which can be easily removed with either fingernails or a dull knife.

4. Remove the faulty keypad by loosening the screws marked with the red arrow.



5. Insert the new keypad and tighten the screws again.
6. Reconnect the keypad to the sauna. Do not worry, if the keypad has extra unused connectors.
7. Make sure the the replacement keypad connector is firmly seated and the wood frame is screwed back in tightly.
8. Reconnect the sauna and enjoy your next sauna session.