


How to Exchange a Power Cable

You will need:

- Phillips head screwdriver (recommended) or battery drill
- Step ladder

Important: Please disconnect the sauna from the power supply before starting


1. Using the step ladder to go to the roof of the sauna. Locate the power cable. The power cable can be found in the left upper corner of your sauna. This may vary depending on the sauna model that you have.
2. Follow the power cable along the inside roof wall of the sauna to the power supply unit (metal box marked with a star on the picture) found under a mesh cut out in the roof. Unscrew enough panels to expose the power supply and power cord connector.



3. Once exposed follow the power cord to where a large molex connector meets the power supply unit. Disconnect the molex connector to release the power cable from the power supply unit and the sauna.



4. Finish removing the power cable by unscrewing all the plastic tabs holding the power cable to the sauna. Take the new power cable and reverse the above steps, making sure the connectors between the power cable and the power supply unit are firmly connected.



5. Reconnect the power supply and enjoy your next sauna session.