

Installation of a Medical Grade Chromotherapy light

You will need:

- Phillips screwdriver or battery dri
- Slotted screwdriver (optional)

Part list:

- Chromotherapy light with holder
- 4 screws
- remote

Important - Please disconnect the sauna from the power supply before you start

1. Remove the center spotlight for the Chromotherapy Light. To do this, lift the holder from the ceiling either with your fingertips or with a slotted screwdriver. When removing the spotlight, pay attention to the spring-loaded catches, as they can snap shut like a mousetrap.



2. Pull the spotlight down until the plug connection is visible. Disconnect the spotlight from the plug. Then push this cable back up into the ceiling.
3. Now you need the red-black cable, which is the second cable located in the hole of the light fitting. You might have to grab inside it and pull it gently. Now connect the red-black cable with the cable on the back of the chromotherapy unit.



4. Fasten the wooden frame of the Chromotherapy Light to the ceiling using the screws supplied. Align the frame centrally above the ceiling hole. Use a tapemeasure to help align the light more accurately.

5. Now reconnect your cabin to the power supply and switch on your Chromotherapy Light with the supplied remote control or the touch sensor on the wooden frame of the spotlight.



6. Enjoy your next sauna session.